Layout R H Side



FRONT ELEVATION



R.H. SIDE ELEVATION



REAR ELEVATION

FUSE SCHEDULE		
FUSE NUMBER	TYPE	RATING
F 1/2/3	[illegible]	[illegible]
F 4/5/6/7/8	[illegible]	[illegible]
F 9/10/11/12	[illegible]	[illegible]
F 13/14/15/16	[illegible]	[illegible]
F 17/18/19/20/21	[illegible]	[illegible]
F 22/23/24/25	[illegible]	[illegible]
F 26/27/28/29	[illegible]	[illegible]
F 30/31/32/33	[illegible]	[illegible]
F 34/35/36/37	[illegible]	[illegible]
F 38/39/40	[illegible]	[illegible]



VIEW INSIDE BASE